ACCESSORY PART NUMBERS

Rain collars, flue adapters, extension cables, ignition kits, integration devices and the VMASS second heater. All accessories are sold separately.

RAIN COLLARS

Shield the spark arrestor from wind-driven rain. Recommended on every installation, especially without a shroud. 316L stainless.

PART NUMBER	FITS	NOTES
XV-RC250	XV150, XV250	
XV-RC350	XV350	

FLUE ADAPTERS: STANDARD

Mount the draft inducer vertically on top of the flue. Selected by flue make, type and size.

PART NUMBER	FLUE (MAKE / TYPE / SIZE)	DRAFT INDUCER
XV-8-XV1250	Round, 8"	XV150, XV250
XV-10-XV1250	Round, 10"	XV150, XV250
XV-12-XV1250	Round, 12"	XV150, XV250
XV-12-XV350	Round, 12"	XV350
XV-14-XV250	Round, 14"	XV150, XV250
XV-14-XV350	Round, 14"	XV350
XV-16-XV350	Round, 16"	XV350
XV-18-XV350	Round, 18"	XV350
XV-13-XV1250	Eco-Steel 13", air-cooled	XV150, XV250
XV-13-XV350	Eco-Steel 13", air-cooled	XV350
XV-13I-XV1250	Eco-Steel+ 13", insulated	XV150, XV250
XV-13I-XV350	Eco-Steel+ 13", insulated	XV350
XV-DM-XV1250	DM54 flue	XV150, XV250
XV-DM-XV350	DM54 flue	XV350
XV-EM40-XV1250	EM40 flue	XV150, XV250
XV-SFA.2-13x13	Clay liner, 13 x 13, flat plate	XV150, XV250
XV-SFA.2-16x16	Clay liner, 16 x 16, flat plate	XV150, XV250
XV-SFA.2-17x17	Clay liner, 17 x 17, flat plate	XV150, XV250
XV-SFA.2-18x18	Clay liner, 18 x 18, flat plate	XV150, XV250
XV-SFA.3-13x17	Clay liner, 13 x 17, flat plate	XV350
XV-SFA.3-16x20	Clay liner, 16 x 20, flat plate	XV350

FLUE ADAPTERS: HORIZONTAL MOUNT

Sidewall termination: the draft inducer mounts at the end of a horizontal flue run, outside the wall. Horizontal runs are specified with an XV250 or XV350 for draft margin.

PART NUMBER	FLUE (MAKE / TYPE / SIZE)	DRAFT INDUCER
XV-HMA250-8	Round, 8"	XV250
XV-HMA250-10	Round, 10"	XV250
XV-HMA250-12	Round, 12"	XV250
XV-HMA250-13	Eco-Steel / Eco-Steel+ 13"	XV250

XV-HMA250-14	Round, 14"	XV250
XV-HMA350-12	Round, 12"	XV350
XV-HMA350-13	Eco-Steel / Eco-Steel+ 13"	XV350
XV-HMA350-14	Round, 14"	XV350

EXTENSION CABLES

Factory-made Molex, plug-in at each end. One continuous cable is best: custom lengths by request. Every extension connection stays accessible, never in conduit or a closed wall.

PART NUMBER	EXTENSION	LENGTH
XV-FANEXT	Draft inducer (white 3-pin)	20 ft
XV-FANEXT50	Draft inducer (white 3-pin)	50 ft
XV-FANEXT100	Draft inducer (white 3-pin)	100 ft
XV-DAMPEREXT	Damper (white 4-pin)	20 ft
XV-DAMPEREXT-50	Damper (white 4-pin)	50 ft
XV-DAMPEREXT-100	Damper (white 4-pin)	100 ft
XV-CONTROLEXT	Wall control (black 6-pin)	20 ft
XV-CONTROLEXT-50	Wall control (black 6-pin)	50 ft
XV-CONTROLEXT-100	Wall control (black 6-pin)	100 ft
XV-IGNEXT-20	Ignition (black 4-pin)	20 ft
XV-IGNEXT-50	Ignition (black 4-pin)	50 ft

IGNITION KITS

Work with every X-VENTISO gas controller: XV-GBC, XV-GBC-DUO, Meridian (XV-MERD-CTRL), Meridian DUO (XV-MERD-DUO), XV-GFDC. Dry contact only.

PART NUMBER	KIT	IGNITION CONTROL
XV-IGN-PFAK	Proflame Automation Kit: switch, remote receiver or automation contact	SIT Proflame 2
XV-IGN-ADPT-RS	Robertshaw Ignition Adapter	Robertshaw 780-715 U

INTEGRATION

Low-voltage signal devices; carry no line voltage.

PART NUMBER	DEVICE	USE
XV-MULTICTRL	Multi Unit Integration Device	Two WBC or two GBC controllers on one wall control (3 to 4 flues). Same fuel only.
XV-INTG	Multiple System Integration Connection	One call to two controllers without a wall control (Meridian, VMASS, GFDC). Daisy-chain for more.

VMASS

PART NUMBER	ITEM	NOTES
XV-VMASS-HTR	Second heater, 2.0 kW	Own dedicated 20 A, 120 V circuit. Every VMASS has two Molex heater connections.

Flue not listed? Round, square, rectangular, masonry, or factory-built: we make custom adapters for any chimney size or setup. Send the flue make, model and size, or a photo of the top of the flue. Dampers: see XV-REF-DMP-PARTS. Questions: 800.642.2920.